

## **PFM** MiniLogger Traffic Counter

---

The **PFM MiniLogger** is a multi-channel datalogger which has been designed to be a completely integrated unit for the collection of customer-traffic-data. The system provides the facilities to count the flow of people in single and dual entrances and collects this information in real time for automatic transfer to the store EPOS system or network environment for further analysis.



The **PFM MiniLogger** can be used in combination with the horizontal infrared beam sensor technology. The unit provides direction logic, which enables to determine not only the daily totals but also the intensity of the traffic by storing the bi-directional traffic per free-adjustable periods. ( Recommended per 30 minutes )



The communication and presentation program **MiniConnect** collects traffic data, stored in the **PFM MiniLogger** and will transfer this to the EPOS, PC or network by using a modem, a nullmodem or a TCP/IP LAN connection. This program will be installed on a local or central PC, which can connect to the **PFM MiniLogger**.



**MiniConnect** can start-up manually or by the windows Task Manager and store the data on the harddisk of the PC. As an option, data can be sent by email to a pre-defined email address by using the local SMTP server. (Note: this option will not be available with Dial-In Connection.)

**Please note that manuals are available for the PFM MiniLogger, all types of sensors and the MiniConnect program and will be sent by email at your request!**

---